



NOTES:

- 1- Place labels on the cable as marked above.
- 2- Place 1 1" shrink tubing 2.5" back from P30 and P32.
- 3- Place 1 1" shrink tubing at the end of J13 and P29.
- 4- Place 1 11" exspando sleaving over the bundle of cables w/ adhesive shrink tubing at each end.

Cloud Cap Technology Inc		
CRISTA IMU DEVELOPERS CABLE		
Title		
Size	Document Number	Rev
B	500-00474-00	1
Date:	Wednesday, October 13, 2004	Sheet 1 of 1